# Meshing with the AyrMesh® IndoorHub






# Why use meshing?

- If you are just using the IndoorHub as a WiFi access point, don't turn on meshing
- If you need multiple access points within a building, strongly consider running Ethernet cable instead of using meshing
- If Ethernet cable is impractical, meshing will allow you to position additional IndoorHubs in the building without running cable.
- One IndoorHub must be connected to the network with an Ethernet cable; it is referred to as the "Gateway" IndoorHub. IndoorHubs connected via meshing are called "Remotes."



# Step 1: Make sure IndoorHub is on your network




IndoorHub should be connected to network with an Ethernet cable, green light steady



# Connect to IndoorHub

- Get the IndoorHub's IP address from AyrMesh.com
- Using a web browser, connect to IndoorHub's web page at http://{IndoorHub's IP address}
- Log in using your AyrMesh.com username and password





# Click on "OPTIONS" Link



## Ayrstone AyrMesh® IndoorHub

Role: Gateway

IP address:

SSID: AyrMesh

Signal strength to next Hub: dBi

Memory free: 35028 Uptime: 0d:0h:10m MAC address:

Channel: 11

Firmware version: 72003

Load: 0.12,0.11,0.07

**OPTIONS** 

#### Site Survey

MAC addr

Chan Signal SSID

### **Client List**

MAC address

Signal strength

---End---



# Click on "Turn on Meshing" box



## Ayrstone AyrMesh® IndoorHub

#### Change 'Rescue' Behavior for networks with/without Internet:

Rescue mode - check for networks WITH Internet connectivity, uncheck for networks WITHOUT Internet connectivity.

### Turn on Meshing - to use IndoorHubs NOT connected to the network:

■ Meshing - check to turn the IndoorHub's Meshing ON, uncheck for Meshing OFF.

#### Turn LEDs on/off:

Signal light on top of IndoorHub - check to turn the IndoorHub's LED ON, uncheck for LED OFF.

Submit



# Then Click on "Submit"



## Ayrstone AyrMesh® IndoorHub

### Change 'Rescue' Behavior for networks with/without Internet:

Rescue mode - check for networks WITH Internet connectivity, uncheck for networks WITHOUT Internet connectivity.

## Turn on Meshing - to use IndoorHubs NOT connected to the network:

Meshing - check to turn the IndoorHub's Meshing ON, uncheck for Meshing OFF.

#### Turn LEDs on/off:

Signal light on top of IndoorHub - check to turn the IndoorHub's LED ON, uncheck for LED OFF.



Submit



# IndoorHub will reboot



# Ayrstone AyrMesh® IndoorHub

IndoorHub is in Rescue mode

Meshing is ON

Light is OFF

INDOORHUB WILL REBOOT NOW



# Notes...


- Set up one IndoorHub at a time. If there are two IndoorHubs with meshing on connected to the network via Ethernet, they will create a network loop and the network will crash
- The light on top of the IndoorHub will indicate the signal strength to the nearest IndoorHub:
  - Flashing green once per second very strong signal
  - Flashing green once every 2 seconds good signal
  - Flashing green once every 3 seconds weak signal
  - Flashing yellow once every second very weak signal
  - Flashing red once every second no signal



# Other options



## Ayrstone AyrMesh® IndoorHub



Rescue mode - check for networks WITH Internet connectivity, uncheck for networks WITHOUT Internet connectivity.

Turn on Meshing - to use IndoorHubs NOT connected to the network:

Meshing - check to turn the IndoorHub's Meshing ON, uncheck for Meshing OFF.


Turn LEDs on/off:

Signal light on top of IndoorHub - check to turn the IndoorHub's LED ON, uncheck for LED OFF.

Submit



# Rescue Mode



Rescue mode automatically reboots the IndoorHub if it misses 10 consecutive checkins to Ayrmesh.com (50 minutes).

If you have a network not connected to the Internet, turn Rescue mode off (uncheck this box) and click "Submit"



# Top LED



The LED on top of the IndoorHub provides useful information about its connectivity, especially if it is being used as a Remote IndoorHub. However, it will always be on and/or blinking, which may be undesirable in some situations.

Unclick the box next to "Signal light on top of IndoorHub" to turn the light off (it will still blink blue when the Hub is booting). Click "Submit."

# Turn LEDs on/off: ✓ Signal light on top of IndoorHub - check to turn the IndoorHub's LED ON, uncheck for LED OFF. Submit

